

WATERPROOF TRAVEL BAG

INSTRUCTIONS

1. Put the right side of the fabric down and the shiny side of the PUL up
2. Clip both ends then surge the short ends leaving a 1" tail
3. Fold the bag leaving 2.5" flap at the top
4. Clip the bottom
5. Iron and heat seal the sides (Only seal the edges and not the middle. It is best to set your iron on the "Steam Wool" setting, if steam is not used it doesn't seal very well)
6. Fold the top 2.5" flap down and surge the sides
7. Lay the bag flat side down. glue down the tails of the surging to keep them in place while you zigzag both sides of the bag.